

Cab

Doors/Group 72

REF. NO.	PART NUMBER	DESCRIPTION	QTY.								
				L1013	L1113	L1116	L1117	L1316	L1317	L1418	LS1418
1	322 720 03 35	Door Lock/Right (Up to Chassis 640358)	1	■	■	■		■		■	■
1	309 720 06 35	Door Lock/Right (From Chassis 640359)	1				■		■		
2	309 720 06 31	Door Latch/Left	1	■	■	■	■	■	■	■	■
2	309 720 07 31	Door Latch/Right	1	■	■	■	■	■	■	■	■
3	112 970 04 01	Arm Rest/Right (Pre Phase II)	1	■	■	■		■		■	■
3	344 970 70 01	Arm Rest/Left (Pre Phase II)	1	■	■	■		■		■	■
4	344 725 70 10	Glass/Door	2	■	■	■		■		■	■
5	344 768 75 01	Window Regulator/Right (Pre Phase II)	1	■	■	■		■		■	■
5	331 725 70 02	Window Regulator/Right (Phase II)	1		■	■	■	■	■	■	■
5	344 768 76 01	Window Regulator/Left (Pre Phase II)	1	■	■	■		■		■	■
5	331 725 71 02	Window Regulator/Left (Phase II)	1		■	■	■	■	■	■	■
6	344 760 00 02	Left and Right Window Crank Handle (Pre Phase II)	2	■	■	■		■		■	■
6	331 725 70 60	Left and Right Window Crank Handle (Phase II)	2		■	■	■	■	■	■	■
7	344 766 01 01	Outside Door Handles with 2 keys <i>Chassis (Up to Chassis 640358)</i>	2	■	■	■		■		■	■
7	376 760 01 59	Outside Door Handles without keys <i>331 760 00 59 Unibel</i> <i>Haga (308 760 03 59 Haga w/Cam)</i>	2				■		■		
8	344 760 00 61	Left Interior Door Handle	1	■	■	■		■		■	■
8	344 760 01 61	Right Interior Door Handle	1	■	■	■		■		■	■
9	322 720 02 16	Door Stop (Pre Phase II)	2	■	■	■		■		■	■
9	331 720 00 16	Door Stop Left (Phase II)	1		■	■	■	■	■	■	■
9	331 720 01 16	Door Stop Right (Phase II)	1		■	■	■	■	■	■	■
10	344 671 70 10	Windshield Glass	1	■	■	■	■	■	■	■	■
11	344 671 71 20	Seal/Windshield	1	■	■	■	■	■	■	■	■
12	344 725 71 10	Vent Window Glass	2	■	■	■	■	■	■	■	■
13	344 678 70 10	Rear Window Glass	2	■	■	■	■	■	■	■	■
14	312 678 04 20	Rear Window Seal	2	■	■	■	■	■	■	■	■
15	344 760 00 65	Lock Knob	2	■	■	■	■	■	■	■	■

A cheap will-fit part can end up being more costly to you than a premium genuine part, if it sidelines a truck and has to be replaced. Buy only genuine Mercedes-Benz replacement parts.

REF. NO.	PART NUMBER	DESCRIPTION	QTY.									
				L1013	L1113	L1116	L1117	L1316	L1317	L1418	LS1418	
16	347 586 00 67	Vent Window Handle Kit/Left	1	■	■	■	■	■	■	■	■	■
16	347 586 01 67	Vent Window Handle Kit/Right	1	■	■	■	■	■	■	■	■	■
17	331 720 72 55	Vent Window Assembly/Left	1	■	■	■	■	■	■	■	■	■
17	331 720 73 55	Vent Window Assembly/Right	1	■	■	■	■	■	■	■	■	■
18	344 768 00 95	Pad, Window Crank (Pre Phase II)	2	■	■	■		■		■	■	
19	000965 004021	Screw (Pre Phase II)	2	■	■	■		■		■	■	
19	000966 006016	Screw (Phase II)	2		■	■	■	■	■			
20	006797 004333	Washer	2	■	■	■	■	■	■	■	■	■
21	344 768 00 13	Washer (Pre Phase II)	2	■	■	■		■		■	■	
22	314 720 00 74	Door Pocket (Phase II)	2		■	■	■		■			
23	000965 006046	Screw	4		■	■	■		■			
24	381 766 00 43	Handle, Door	2		■	■	■		■			
25	331 723 00 69	Rod	2		■	■	■		■			
26	331 760 70 59	Inside Door Pull Handle (Up to Cab Number 477376)	2		■	■	■		■			
26	331 760 71 59	Inside Door Pull Handle (From Cab Number 477377)	2		■	■	■		■			
27	344 723 01 69	Rod, Pull Lock	2	■	■	■	■	■	■	■	■	■

Grille/Group 75

